


When you sit down, the pads accompany your body as it moves from an angle of +8 degrees to -2 degrees. Your weight is then gradually supported by the pneumatic cushions, limiting user efforts.

Technical drawing of pneumatic cushions .



The air cushions hardness is easily adjusted by a scroll wheel.

Detail of air valve to fill the frame in air.

